


CIRCUIT INSPECTION

Power source circuit

CIRCUIT DESCRIPTION

This circuit provides power to operate the Body ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check ECU-B fuse.****CHECK:**

Check continuity of ECU-B fuse.

OK:

Continuity

NG**Replace the failure fuse.****OK****2 Check voltage between terminals BECU and GND of Body ECU connector.****PREPARATION:**

- (a) Turn ignition switch OFF.
- (b) Disconnect the Body ECU connector.

CHECK:

Measure voltage between terminals BECU and GND.

OK:

Voltage: 10 – 14V

OK**Proceed to next circuit inspection shown on problem symptoms table. (See page [DI-702](#))****NG****3 Check wireharness and connector between Body ECU and body ground.****NG****Repair or replace wireharness or connector.****OK**

Check and repair wireharness and connector between Body ECU and battery.