




ELECTRONICALLY CONTROLLED TRANSMISSION AND A/T INDICATOR





[illegible]



ELECTRONICALLY CONTROLLED TRANSMISSION AND A/T INDICATOR

SYSTEM OUTLINE

The electronically controlled transmission electrically controls the, throttle pressure, lock-up pressure, and accumulator pressure etc. through the solenoid valve.

The electronically controlled transmission is a system which precisely controls the gear shift timing and lock-up timing in response to the vehicle's driving conditions and the engine condition detected by various sensors. It makes smooth driving possible by shift selection of the gear which is the most appropriate to the driving conditions at that time, and by preventing downing, squat and gear shift shock when starting off.

1. GEAR SHIFT OPERATION

When driving, the engine warm up condition is input as a control signal from the engine coolant temp. sensor to TERMINAL THW of the engine control module, and the vehicle speed is input to TERMINAL SP2+ of the engine control module from the vehicle speed sensor. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINALS VTA, VTA2 of the engine control module as a throttle angle signal. Based on these signals, the engine control module selects the best shift position for the driving conditions and sends current to the electronically controlled transmission solenoid.

2. LOCK-UP OPERATION

When the engine control module decides based on each signal that the lock-up condition has been met, the current flows from the engine control module TERMINAL SL to TERMINAL 7 of the electronically controlled transmission solenoid to GROUND.

3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up position, a signal is input to TERMINAL STP of the engine control module. As a result, the engine control module cuts the current to the solenoid to release the lock-up.

4. ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW CIRCUIT

When the electronically controlled transmission pattern select SW is switched to PWR, a signal is input to TERMINAL PWR of the engine control module, and the engine control module controls to enable shift-up and shift-down at a higher speed range than usual. In that case, the ECT PWR indicator light in the combination meter is lit up. When the electronically controlled transmission pattern select SW is switched to 2nd position, a signal is input to the engine control module TERMINAL SNWI, and through control of the engine control module, the gear shift of the transmission is made from 2nd position. The 2nd STRT indicator light in the combination meter is lit up.

5. OVERDRIVE CIRCUIT

* O/D main SW on

When the O/D main SW is switched to ON position, a signal is input to TERMINAL OD2 of the engine control module, and enables shift change to the overdrive range, through the control of the engine control module.

* O/D main SW off

When the O/D main SW is switched to OFF position, a signal is input to TERMINAL OD2 of the engine control module, and prohibits shift change to the overdrive range through the control of the engine control module. When in the overdrive range already, shift down is made.

6. TRANSFER SHIFT OPERATION

When the transfer shift lever is moved to L position, a signal is input into TERMINAL L4 of the engine control module.

In addition when the transfer shift lever is moved to N position a signal is input to engine control module TERMINAL TFN.

The engine control module detects the transfer condition through this.

SERVICE HINTS

E5 ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW

5-3 : Closed with select SW at **PWR** position

2-3 : Closed with select SW at **2nd** position

E7 (B), E9 (D), E10 (E) ENGINE CONTROL MODULE

BATT-E1 : Always **9.0-14.0** volts

+B-E1 : **9.0-14.0** volts with ignition SW at **ON** or **ST** position

+B1-E1 : **9.0-14.0** volts with ignition SW at **ON** or **ST** position

NSW-E1 : **9.0-14.0** volts with ignition SW on and other shift lever in **P** and **N** position

: **0-3.0** volts with ignition SW on and shift lever in **P** or **N** position

STA-E1 : **6.0** volts or more with ignition SW at **ST** position and shift lever in **P** or **N** position

P1 A/T INDICATOR LIGHT SW [PARK/NEUTRAL POSITION SW]

4-7 : Closed with shift lever in **P** position

4-8 : Closed with shift lever in **R** position

4-10 : Closed with shift lever in **N** position

4-9 : Closed with shift lever in **D** position

4-2 : Closed with shift lever in **2** position

4-3 : Closed with shift lever in **L** position

○ : PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
A6		36	E8	C	38	J21	39
A13		36	E9	D	38	J22	39
C14	A	38	E10	E	38	J23	39
C15	B	38	F7		36	J27	39
C16	C	38	I18		38	O1	37
C17	D	38	J1		39	O3	39
D1		36	J7		39	P1	37
D5		36	J8		39	S5	39
D6		36	J11		39	T3	37
E1		36	J14		39	T4	37
E2		36	J17		39	V2	37
E5		38	J18		39	V3	37
E6	A	38	J19		39		
E7	B	38	J20		39		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	21	Engine Room No.2 Wire and Engine Room J/B (Engine Compartment Left)
1D		
1E		
1N	21	Engine Room No.3 Wire and Engine Room J/B (Engine Compartment Left)
2B	24	Dash Wire and Cowl Side J/B LH (Left Kick Panel)
2D		
2P	26	Instrument Panel Integration Wire and Cowl Side J/B LH (Left Kick Panel)

ELECTRONICALLY CONTROLLED TRANSMISSION AND A/T INDICATOR

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS















Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	44	Engine Wire and Transmission Wire (On the Transmission)
EB2		
IG1	48	Engine Room No.2 Wire and Dash Wire (Behind the Combination Meter)
IG2		
IK1	48	Console Box Wire and Dash Wire (Left Side of Front Console)
IL1	48	Instrument Panel Integration Wire and Computer Wire (Instrument Panel Center)
IN1	50	Engine Wire and Dash Wire (Behind the Glove Box)
IO2		
IU1	50	Instrument Panel Integration Wire and Dash Wire (Behind the Glove Box)
IU3		
IW1	52	Engine Room No.2 Wire and Dash Wire (Behind the Glove Box)
IX1	52	Instrument Panel Integration Wire and Engine Wire (Behind the Glove Box)

: GROUND POINTS


Code	See Page	Ground Points Location
EC	44	Rear Bank of Right Cylinder Head
EE	44	Front Left Side of Fender Apron
IF	46	Set Bolt of Cowl Side J/B LH
IG		

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	44	Engine Wire	I10	48	Dash Wire
I5	48	Dash Wire	I11		
I9	48	Console Box Wire			




F7
(See Page 34)




ELECTRONICALLY CONTROLLED TRANSMISSION AND A/T INDICATOR

J1




(Hint : See Page 7)

J7
BLUE




(Hint : See Page 7)

J8
BLUE




(Hint : See Page 7)

J11
GREEN




(Hint : See Page 7)

J14




(Hint : See Page 7)

J17




(Hint : See Page 7)

J18
GRAY




(Hint : See Page 7)

J19




(Hint : See Page 7)

J20
GRAY




(Hint : See Page 7)

J21
BLUE




(Hint : See Page 7)

J22
RED




(Hint : See Page 7)

J23
BLUE




(Hint : See Page 7)

J27




(Hint : See Page 7)


O1
BLACK




O3



P1
GRAY



S5
BLUE



T3
GRAY



T4
GRAY



V2
BLACK



V3
BLACK

