


G ELECTRICAL WIRING ROUTING

Position of Parts in Engine Compartment



- A 1 A/C Ambient Temp. Sensor
- A 2 A/C Condenser Fan Motor
- A 3 A/C Condenser Fan Relay
- A 4 A/C Magnetic Clutch and Lock Sensor
- A 5 A/C Triple Pressure SW
(A/C Dual and Single Pressure SW)
- A 6 A/T Oil Temp. Sensor
- A 7 ABS Actuator
- A 8 ABS Actuator
- A 9 ABS Actuator
- A 10 ABS Actuator
- A 11 ABS Speed Sensor Front LH
- A 12 ABS Speed Sensor Front RH
- A 13 Accel Position Sensor
- A 14 AHC Pump Motor
- A 15 Airbag Sensor Front LH
- A 16 Airbag Sensor Front RH
- A 17 Auto Antenna Motor

- C 1 Camshaft Position Sensor
- C 2 Center Diff. Lock Control Motor
- C 3 Crankshaft Position Sensor


- D 1 Data Link Connector 1
- D 2 Daytime Running Light Relay No.3
- D 3 Daytime Running Light Relay No.3
- D 4 Detection SW (Center Diff. Lock)
- D 5 Detection SW (Transfer L Position)
- D 6 Detection SW (Transfer Neutral Position)

- E 1 Electronically Controlled Transmission Solenoid
- E 2 Engine Coolant Temp. Sensor
- E 3 Engine Hood Courtesy SW
- E 4 Exhaust Gas Sensor

- F 1 Fluid Pressure Sensor
- F 2 Front Fog Light LH
- F 3 Front Fog Light RH
- F 4 Front Turn Signal Light LH
- F 5 Front Turn Signal Light RH
- F 6 Front Wiper Motor
- F 7 Fusible Link Block

- G 1 Generator
- G 2 Generator

Position of Parts in Engine Compartment



H 1 Headlight Cleaner Control Relay

H 2 Headlight Cleaner Motor

H 3 Headlight LH (High)

H 4 Headlight LH (Low)

H 5 Headlight RH (High)

H 6 Headlight RH (Low)

H 7 Heated Oxygen Sensor (Bank 1 Sensor 1)

H 8 Heated Oxygen Sensor (Bank 1 Sensor 2)

H 9 Heated Oxygen Sensor (Bank 2 Sensor 1)

H10 Heated Oxygen Sensor (Bank 2 Sensor 2)

H11 Height Control Sensor Front LH

H12 Height Control Sensor Front RH

H13 Horn LH

H14 Horn RH

I 1 Ignition Coil and Igniter No.1

I 2 Ignition Coil and Igniter No.2

I 3 Ignition Coil and Igniter No.3

I 4 Ignition Coil and Igniter No.4

I 5 Ignition Coil and Igniter No.5

I 6 Ignition Coil and Igniter No.6

I 7 Ignition Coil and Igniter No.7

I 8 Ignition Coil and Igniter No.8

I 9 Injector No.1

I 10 Injector No.2

I 11 Injector No.3

I 12 Injector No.4

I 13 Injector No.5

I 14 Injector No.6

I 15 Injector No.7

I 16 Injector No.8

K 1 Knock Sensor 1

K 2 Knock Sensor 2

M 1 Mass Air Flow Meter

N 1 Noise Filter (Ignition)

O 1 O/D Direct Clutch Speed Sensor

O 2 Oil Pressure Sender

P 1 Park/Neutral Position SW, A/T Indicator Light SW and Back-Up Light SW

P 2 Parking Light and Side Marker Light LH

P 3 Parking Light and Side Marker Light RH

S 1 Starter

S 2 Starter

T 1 Temp. Sensor (AHC)

T 2 Theft Deterrent Horn

T 3 Throttle Control Motor

T 4 Throttle Position Sensor

V 1 Vapor Pressure Sensor

V 2 Vehicle Speed Sensor (Combination Meter)

V 3 Vehicle Speed Sensor (Electronically Controlled Transmission)

V 4 VSV (EVAP)

V 5 VSV (Vapor Pressure Sensor)


W 1 Washer Motor

W 2 Water Temp. Sender

W 3 Wireless Door Lock Buzzer

G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel



A18 A/C Solar Sensor
 A19 A/C Thermistor
 A20 ABS Deceleration Sensor
 A21 ABS ECU
 A22 ABS ECU
 A23 ABS ECU
 A24 AHC Main Relay
 A25 Air Inlet Control Servo Motor
 A26 Air Mix Control Servo Motor
 A27 Air Vent Mode Control Servo Motor
 A28 Airbag Squib (Front Passenger Airbag Assembly)
 A29 Airbag Squib (Steering Wheel Pad)
 A30 Ashtray Illumination
 A31 Auto Antenna Control Relay
 A32 Automatic Light Control Sensor

B 1 Blower Motor Controller

C 4 Cellular Phone (Hand Set)
 C 5 Cellular Phone (Hand Set)
 C 6 Center Airbag Sensor Assembly
 C 7 Center Diff. Lock Control Relay
 C 8 Center ECU
 C 9 Center ECU
 C10 Center ECU
 C11 Center ECU
 C12 Cigarette Lighter
 C13 Cigarette Lighter Illumination
 C14 Combination Meter
 C15 Combination Meter

C16 Combination Meter
 C17 Combination Meter
 C18 Combination SW
 C19 Combination SW
 C20 Combination SW
 C21 Combination SW

D 7 Damping Mode Select SW and Height Control SW
 D 8 Data Link Connector 3
 D 9 Daytime Running Light Relay (Main)

E 5 Electronically Controlled Transmission Pattern Select SW


E 6 Engine Control Module
 E 7 Engine Control Module
 E 8 Engine Control Module
 E 9 Engine Control Module
 E10 Engine Control Module

F 8 Fuel Control SW

G 3 Glove Box Light

I 17 Ignition Key Cylinder Light
 I 18 Ignition SW
 I 19 Instrument ECU
 I 20 Instrument ECU
 I 21 Instrument ECU

Position of Parts in Instrument Panel



J 1 Junction Connector
 J 2 Junction Connector
 J 3 Junction Connector
 J 4 Junction Connector
 J 5 Junction Connector
 J 6 Junction Connector
 J 7 Junction Connector
 J 8 Junction Connector
 J 9 Junction Connector
 J 10 Junction Connector
 J 11 Junction Connector
 J 12 Junction Connector
 J 13 Junction Connector
 J 14 Junction Connector
 J 15 Junction Connector
 J 16 Junction Connector
 J 17 Junction Connector
 J 18 Junction Connector
 J 19 Junction Connector
 J 20 Junction Connector
 J 21 Junction Connector
 J 22 Junction Connector
 J 23 Junction Connector
 J 24 Junction Connector
 J 25 Junction Connector
 J 26 Junction Connector
 J 27 Junction Connector
 J 28 Junction Connector
 J 29 Junction Connector
 J 30 Junction Connector

K 3 Key Interlock Solenoid

O 3 O/D Main SW and Shift Lock Control ECU

P 4 Power Outlet (Front)
 P 5 Power Outlet (Rear Console Box)
 P 6 Power Quarter Window SW LH
 P 7 Power Quarter Window SW RH

R 1 Radio and Player
 R 2 Rear Diff. Lock Control ECU
 R 3 Rear Diff. Lock SW
 R 4 Remote Control Mirror SW
 R 5 Remote Control Mirror SW
 R 6 Rheostat
 R 7 Room Temp. Sensor (Front)

S 3 Seat Heater SW (Driver's Seat)
 S 4 Seat Heater SW (Front Passenger's Seat)
 S 5 Stop Light SW
 S 6 Suspension Control ECU
 S 7 Suspension Control ECU
 S 8 Suspension Control ECU

T 5 Telescopic Motor
 T 6 Theft Deterrent ECU
 T 7 Theft Deterrent ECU
 T 8 Tilt and Telescopic ECU
 T 9 Tilt and Telescopic ECU
 T 10 Tilt Motor
 T 11 Transponder Key Amplifier
 T 12 Turn Signal Flasher


U 1 Unlock Warning SW

W 4 Wireless Door Lock ECU

G ELECTRICAL WIRING ROUTING

Position of Parts in Body

*1 : w/ Moon Roof
*2 : w/o Moon Roof



A33 A/C Amplifier
A34 A/C Amplifier
A35 A/C Amplifier
A36 ABS Speed Sensor Rear LH
A37 ABS Speed Sensor Rear RH
A38 Accumulator Solenoid

B 2 Back Door Courtesy SW
B 3 Back Door Key Lock and Unlock SW
B 4 Back Door Lock Motor and
Back Door Unlock Detection SW

C22 Control Valve Assembly

D10 Damping Force Control Actuator Front LH
D11 Damping Force Control Actuator Front RH
D12 Damping Force Control Actuator Rear LH
D13 Damping Force Control Actuator Rear RH
D14 Detection SW (Rear Diff. Lock)
D15 Door Courtesy Light Front LH
D16 Door Courtesy Light Front RH
D17 Door Courtesy Light Rear LH
D18 Door Courtesy Light Rear RH
D19 Door Courtesy SW Front LH
D20 Door Courtesy SW Front RH
D21 Door Courtesy SW Rear LH
D22 Door Courtesy SW Rear RH
D23 Door Key Lock and Unlock SW LH
D24 Door Key Lock and Unlock SW RH
D25 Door Lock Control SW RH

D26 Door Lock Motor and Door Unlock Detection SW Front LH
D27 Door Lock Motor and Door Unlock Detection SW Front RH
D28 Door Lock Motor and Door Unlock Detection SW Rear LH
D29 Door Lock Motor and Door Unlock Detection SW Rear RH
D30 Driving Position Memory SW

F 9 Front Door Speaker LH
F10 Front Door Speaker RH
F11 Front Interior light and Rear Personal Light
F12 Front Personal Light
F13 Fuel Pump and Sender
F14 Fuel Pump Control ECU


G 4 Garage Door Opener

H15 Height Control Sensor Rear
H16 High Mounted Stop Light

I 22 Inner Mirror

J31 Junction Connector
J32 Junction Connector
J33 Junction Connector
J34 Junction Connector
J35 Junction Connector
J36 Junction Connector
J37 Junction Connector
J38 Junction Connector
J39 Junction Connector
J40 Junction Connector

Position of Parts in Body



L 1 License Plate Light LH
L 2 License Plate Light RH

M 2 Moon Roof Control ECU
M 3 Moon Roof Control SW

P 8 Parking Brake SW
P 9 Power Outlet (Luggage Compartment)
P10 Power Vent Window Motor LH
P11 Power Vent Window Motor RH
P12 Power Window Control SW Front RH
P13 Power Window Control SW Rear LH
P14 Power Window Control SW Rear RH
P15 Power Window Master SW
P16 Power Window Motor Front LH
P17 Power Window Motor Front RH
P18 Power Window Motor Rear LH
P19 Power Window Motor Rear RH
P20 Pretensioner LH
P21 Pretensioner RH

R 8 Rear A/C Control SW
R 9 Rear Air Mix Control Servo Motor
R10 Rear Combination Light LH
R11 Rear Combination Light LH
R12 Rear Combination Light RH
R13 Rear Combination Light RH
R14 Rear Cooler Blower Motor
R15 Rear Cooler Magnetic Valve
R16 Rear Cooler Power Transistor
R17 Rear Cooler Relay
R18 Rear Diff. Lock Motor

R19 Rear Door Speaker LH
R20 Rear Door Speaker RH
R21 Rear Evaporator Temp. Sensor
R22 Rear Heater Blower Motor
R23 Rear Heater Power Transistor
R24 Rear Inlet Air Temp. Sensor
R25 Rear Interior Light
R26 Rear Window Defogger
R27 Rear Window Defogger
R28 Rear Wiper Motor
R29 Rear Wiper Relay
R30 Remote Control Mirror ECU
R31 Remote Control Mirror LH
R32 Remote Control Mirror RH
R33 Room Temp. Sensor (Rear)

S 9 Stereo Component Amplifier
S10 Stereo Component Amplifier
S11 Stereo Component Amplifier
S12 Stereo Component Amplifier

T13 Telephone Transceiver and Speaker Relay
T14 Telephone Transceiver and Speaker Relay
T15 Trailer Socket
T16 Tweeter LH
T17 Tweeter RH

V 6 Vanity Light LH
V 7 Vanity Light RH

W 5 Woofer (Speaker)

G ELECTRICAL WIRING ROUTING

Position of Parts in Seat

