



## INSPECTION

### INSPECT LOWER SUSPENSION ARM BALL JOINT FOR ROTATION CONDITION

- (a) As shown in the illustration, flip the ball joint stud back and forth 5 times, before installing the nut.
- (b) Using a torque wrench, turn the nut continuously 1 turn per 3 – 5 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**0.29 – 2.94 N·m (3 – 30 kgf·cm, 2.6 – 26 in.·lbf)**