

EVAPORATOR

INSPECTION

AC2RJ-03

1. REMOVE EVAPORATOR (See page [AC-26](#))
2. CHECK EVAPORATOR FINS FOR BLOCKAGE

If the fins are clogged, clean them with compressed air.

NOTICE:

Never use water to clean the evaporator.

3. CHECK FITTINGS FOR CRACKS OR SCRATCHES

Repair as necessary.

4. REINSTALL EVAPORATOR (See page [AC-26](#))