




# HEATER MAIN RELAY INSPECTION

AC25E-03

## INSPECT HEATER MAIN RELAY CONTINUITY

| Condition                           | Tester connection | Specified condition |
|-------------------------------------|-------------------|---------------------|
| Constant                            | 1 - 3<br>2 - 4    | Continuity          |
| Apply B+ between terminals 3 and 5. | 4 - 5             | Continuity          |

If continuity is not as specified, replace the relay.