





DISASSEMBLY

1. DISCONNECT SLIDING ROOF GUIDE RAIL AND CABLE GUIDE CASING

- Remove the screw and guide rail cover.
- Remove the screw.
- Pull out the cable guide casing.



2. REMOVE SLIDING GUIDE RAIL

- Make the drive cable to the front edge.
- Remove the 4 screws and both side drive rails.
- Remove the sunshade trim.