

INSTALLATION

Installation is in the reverse order of removal (See page [BR-25](#)).

HINT:

After installation, fill the brake reservoir with brake fluid, bleed brake system (see page [BR-4](#)) and check for leaks.