




MA04W-01

BODY INSPECTION

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

- (a) Tighten the front seat-to-body mounting bolts.

Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)

- (b) Under Severe Conditions:

In addition to the above maintenance items, check for loose or missing nuts and bolts on the steering system, drive train, suspension system, fuel tank mounts, engine mounts, etc.

2. FINAL INSPECTION

- (a) Check the operation of the body parts:

- Hood:
Auxiliary catch operates properly
Hood locks securely when closed
- Front and rear doors:
Door locks operate properly
Doors close properly
- Back door:
Door lock operates properly
- Seats:
Seat adjusts easily and locks securely in any position
Front seat back locks securely in any position
Folding-down rear seat backs lock securely

- (b) Road test

- Check the engine and chassis for abnormal noises.
- Check that the vehicle does not wander or pull to one side.
- Check that the brakes work properly and do not drag.

- (c) Be sure to deliver a clean car.

Especially check the steering wheel, shift lever knob, all switch knobs, door handles and seats.