

EQUIPMENT

Bulb (3.4 W)	Fuel sender gauge Seat belt warning relay
Bulb (21 W)	Turn signal flasher relay
Clip remover	For removing cowl louver
Dry cell battery	Fuel sender gauge
Masking tape	Rear window defogger wire
Oil bath	Engine oil level warning switch
Test lead	
Thermometer	Engine coolant temperature sender gauge Engine oil level warning switch
Tin foil	Rear window defogger wire
Torque wrench	