



## REASSEMBLY

Reassembly is in the reverse order of disassembly (See page [BR-48](#)).

### INSTALL ACCUMULATOR BRACKET

When installing the accumulator bracket, adjust to secure the clearance shown in the illustration on the left.

#### Standard clearance:

**A + B: 4.1 mm (0.161 in.) or less**

**C: 0.3 mm (0.012 – 0.150 in.)**

#### HINT:

Secure more than 0.3 mm (0.012 in.) clearance for A and B each.