

## INSTALLATION

Installation is in the reverse order of removal (See page [BR-25](#)).

1. AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID AND BLEED BRAKE SYSTEM (See page [BR-4](#))
2. CHECK FOR LEAKS