


# GARAGE DOOR OPENER

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



## SERVICE HINTS

### G4 GARAGE DOOR OPENER

2-GROUND : Always approx. 12 volts

1-GROUND : Always continuity

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
G4	40				

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	24	Roof Wire and Cowl Side J/B LH (Left Kick Panel)

### : GROUND POINTS

Code	See Page	Ground Points Location
IF	46	Set Bolt of Cowl Side J/B LH

### G4

