

CIRCUIT INSPECTION

DTC	P0500/21,23	Vehicle Speed Sensor Circuit
------------	--------------------	-------------------------------------

CIRCUIT DESCRIPTION

See page [DI-113](#).

DTC No.	Detection Item	Trouble Area
P0500/21,23	Speed signal is not input to the ECM while cruise control is set.	<ul style="list-style-type: none">• Combination meter• Harness or connector between ECM and vehicle speed sensor• Vehicle speed sensor• ECM

WIRING DIAGRAM

See page [DI-113](#).

INSPECTION PROCEDURE

See page [DI-113](#).