

## EQUIPMENT

Voltmeter	
Ammeter	
Ohmmeter	
Test lead	
Thermometer	Engine coolant temperature sender gauge, Engine oil level warning switch, Seat heater
Syphon	Brake fluid level warning switch
Oil bath	Engine oil level warning switch
Bulb (1.4 W)	Defogger switch
Bulb (3.4 W)	Fuel sender gauge, Engine coolant temperature receiver gauge, Seat belt warning relay
Dry cell battery	Fuel sender gauge, Power mirror
Heat light	Seat heater
Hexagon wrench (6 mm)	Power seat
Torque wrench	
Masking tape	Rear window defogger wire
Tin foil	Rear window defogger wire