

## TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
No.1 vehicle speed sensor lock plate x Transfer case		16	160	12
No.2 vehicle speed sensor x Transmission case		5.4	55	48 in.·lbf
ATF temperature sensor x Oil cooler elbow		15	150	11
Park/neutral position switch	Bolt	13	130	9
	Nut	3.9	40	35 in.·lbf
Transmission control shaft lever x Park/neutral position switch		16	160	12
Transmission control shaft lever x Transmission control rod		13	130	9
Shift solenoid valve x Valve body		11	110	8
Detent spring x Valve body		10	100	7
Valve body x Transmission case		10	100	7
Oil stainer x Valve body		10	100	7
Oil pan x Transmission case		7.4	75	65 in.·lbf
Drain plug x Oil pan		20	205	15
Parking lock pawl bracket x Transmission case		7.4	75	65 in.·lbf
Shift lever assembly x Body		5.4	55	48 in.·lbf
Control rod x Shift lever plate		13	130	9
Oil cooler bracket x Body		11	115	8
Oil cooler bracket x Oil cooler		4.9	50	43 in.·lbf
Oil cooler pipe stay x Body		5.0	51	44 in.·lbf
Oil filler pipe		11.5	120	8
Transfer shift lever boot x Body		5.4	55	48 in.·lbf
Hole plug x Transmission housing		18	185	13
Drive plate x Torque converter clutch		48	490	35
Oil cooler pipe union nut		69	700	51
Crossmember	Bolt	61	620	45
	Nut	74	750	54
Transmission housing x Engine		72	730	53
Drive plate x Crankshaft	1st	49	500	36
	2nd	Turn 90°	Turn 90°	Turn 90°