

INSPECTION

1. CHECK EVAPORATOR FINS FOR BLOCKAGE

If the fins are clogged, clean them with compressed air.

NOTICE:

Never use water to clean the evaporator.

2. CHECK FITTINGS FOR CRACKS OR SCRATCHES

If necessary, repair or replace.

3. INSPECT EVAPORATOR TEMPERATURE CIRCUIT (See page [DI-786](#))