


# J OVERALL ELECTRICAL WIRING DIAGRAM

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

## HOW TO READ THIS SECTION



**[A]** : System Title


**[B]** : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black    W = White    BR = Brown  
L = Blue    V = Violet    SB = Sky Blue  
R = Red    O = Orange    LG = Light Green  
P = Pink    Y = Yellow    GR = Gray  
G = Green

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L – Y




**[C]** : The position of the parts is the same as shown in the wiring diagram and wire routing.


**[D]** : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left



Female



Male


The numbering system for the overall wiring diagram is the same as above

**[E]** : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : ① Indicates Relay Block No.1


**[F]** : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



**[G]** : Indicates related system.

**[H]** : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗). Outside numerals are pin numbers.



**[I]** : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

**[J]** : Indicates a shielded cable.



**[K]** : Indicates and located on ground point.

**[L]** : The same code occurring on the next page indicates that the wire harness is continuous.

## SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS .....	15-2	Power Outlet .....	24-2
Active Height Control Suspension and Adaptive Variable Suspension .....	16-2	Power Rear Quarter Window .....	25-3
Auto Antenna .....	12-3	Power Seat .....	21-2
Automatic Glare-Resistant EC Mirror .....	24-3	Power Source .....	1~32-1
Back-Up Light .....	8-2	Power Tilt and Power Telescopic .....	22-2
Cellular Mobile Telephone .....	28-2	Power Window .....	20-2
Center Differential Lock .....	17-2	Radio and Player .....	29-2
Charging .....	1-3	Rear Air Conditioning .....	32-2
Cigarette Lighter .....	27-2	Rear Differential Lock .....	18-2
Clock .....	9-4	Rear Window Defogger and Mirror Heater .....	25-2
Combination Meter .....	30-2	Remote Control Mirror .....	23-2
Condenser Fan and Front Air Conditioning .....	31-2	Seat Heater .....	27-3
Cruise Control .....	14-2	Shift Lock .....	12-2
Electronically Controlled Transmission and A/T Indicator .....	14-3	SRS .....	13-2
Engine Control and Engine Immobiliser System .....	2-2	Starting .....	1-2
Front Fog Light .....	4-2	Stop Light .....	8-3
Front Wiper and Washer .....	11-2	Taillight .....	6-2
Garage Door Opener .....	9-3	Theft Deterrent .....	19-2
Headlight .....	4-3	Turn Signal and Hazard Warning Light .....	5-2
Headlight Cleaner .....	9-2		
Horn .....	11-4		
Ignition .....	3-2		
Illumination .....	7-2		
Key Reminder and Seat Belt Warning .....	26-2		
Moon Roof .....	26-3		
Multiplex Communication System .....	10-2		