



INSPECTION

INSPECT UPPER SUSPENSION ARM BALL JOINT FOR ROTATION CONDITION

- (a) As shown in the illustration, flip the ball joint stud back and forth 5 times, before installing the nut.
- (b) Using a torque wrench, turn the nut continuously 1 turn per 3 – 5 seconds and take the torque reading on the 5th turn.

Turning torque:

1.0 – 4.4 N·m (10 – 45 kgf·cm, 8.7 – 39 in.·lbf)