

INSPECTION

INSPECT WASHER NOZZLE

- (a) While operating the washer, check if the point where the washer fluid hits the windshield is within the range indicated by the hatched line.

A: Approx. 311 mm (12.24 in.)

B: Approx. 110 mm (4.33 in.)

C: Approx. 61 mm (2.40 in.)

D: Approx. 116 mm (4.57 in.)

E: Approx. 117 mm (4.61 in.)

F: Approx. 22 mm (0.87 in.)

G: Approx. 138 mm (5.43 in.)

H: Approx. 60 mm (2.36 in.)

I: Approx. 85 mm (3.35 in.)

J: Approx. 364 mm (14.33 in.)

K: Approx. 496 mm (19.53 in.)

L: Approx. 81 mm (3.19 in.)

M: Approx. 35 mm (1.38 in.)

N: Approx. 157 mm (6.18 in.)

O: Approx. 159 mm (6.26 in.)

P: Approx. 63 mm (2.48 in.)

Q: Approx. 144 mm (5.67 in.)

R: Approx. 331 mm (13.03 in.)

S: Approx. 465 mm (18.31 in.)


T: Approx. 468 mm (18.43 in.)

U: Approx. 45 mm (1.77 in.)

V: Approx. 104 mm (4.09 in.)

W: Approx. 94 mm (3.70 in.)

- (b) Check that the lower point where the washer fluid hits the windshield is within the range of the wiping pattern (the area of the glass which is wiped by the blades).



H04842